

# HOW TO CLEAN YOUR ROOM'S VACUUM CLEANER

For All residents!

## 1 DISASSEMBLE THE VACUUM HEAD



Disassemble it into three parts!

Separate the vacuum head into three parts:



Brush Roller

Bottom Cover

## 2 REMOVE DUST & DIRT, THEN REASSEMBLE



Remove all the dust!

Remove dust, hair, and debris from the vacuum head, then put it back together.

All clean!


Clean your vacuum regularly to keep it running well!




# Easy Care Guide

## Dust Cup Care


Be sure to dispose of your trash before crossing the dump line





### 1 Throw away the trash in a cup



### 2 Discard filter debris




### 3 when dirt is a concern...



※ Please soak into water for hours to remove all dust

### 6 Dry completely




if used with insufficient drying, bacteria can grow & cause exhaust odors.

➔ Continues on back page


## Assemble

# 4



### Care of cleaner head

## Cleaning of the rotating part



\*If you see an orange light blinking,  
please first try to clean by following these steps.

\*The light is still on, please contact us.

**\*A daily cleaning is necessary for the maintenance.**

*Thank you for your cooperation.*



SF Cleaning Robot says:

**Keep it clean for best performance!**

